Software Defined Radio

AN5014



Introduction (Ask a Question)

A Software-Defined Radio (SDR) is a communication system that utilizes a programmable medium to implement radio components like mixers, filters, modulators/demodulators, and detection circuits. This approach offers enhanced flexibility and capabilities in the system.

A well-designed Software-Defined Radio (SDR) typically comprises various fixed components, such as an antenna, front-end RF hardware, and an ADC or DAC. The remaining functionalities are implemented in a programmable medium, referred to as "soft" components. While general-purpose processors are commonly used for this purpose, they often lack the required I/O bandwidth and processing capabilities, except for the most basic SDR architectures. FPGA systems fulfill the demands of complex SDR implementations by offering both the necessary I/O bandwidth and processing capabilities.

This demonstration outlines an SDR application on the PolarFire[®] FPGA. Baseband processing is implemented on the FPGA and transmitted using a wideband RF transceiver, AD9371. The transceiver is configured via a soft Mi-V processor on the PolarFire FPGA.

This design demonstrates the following features:

- Supports Wireless transmission of text or image files between two hardware setups
- Supports the UART GUI to transmit and receive the data
- Supports configuration of the AD9371 RF board using the Mi-V soft processor on FPGA device
- Provides carrier frequency and phase offset correction using Costas loop
- Supports FEC encoding to correct data transmission errors
- Supports Symbol Timing Synchronization
- Supports Custom Packetization and Depacketization Method
- Supports configurable parameters for wide range blocks

The demo includes a user-friendly SDR Graphical User Interface (GUI) to configure transmit and receive data.

The Microchip PolarFire FPGA Evaluation Kit (MPF300-EVAL-KIT), which is RoHS-compliant, enables you to evaluate the PolarFire family of FPGAs with support for the following interfaces:

- PCI Express Gen1 and Gen2
- 1 GbE
- DDR3 and DDR4 memory
- FMC HPC with eight transceiver lanes
- One full-duplex Transceiver SMAs
- SFP+ Cage
- UART interface to FTDI device
- SPI interface to SPI Flash device

For more information about the PolarFire Evaluation kit, see PolarFire FPGA Evaluation Kit.

Table of Contents

Intr	oduction	1								
1.	Demo Requirements									
2.	. Demo Prerequisites4									
3.	Demo Design	5 5 5								
	 3.3. Transmitter	5 6 6 7								
	3.7. Resource Utilization and Performance	9 9								
4.	Installing the Software Defined Radio Demo GUI1	1								
5.	Setting Up the Demo.125.1.Setting Up the Hardware.5.2.Programming the Device.12	2 2 3								
6.	SoftConsole10	6								
7.	Running the Demo17.1. Running the Demo on Same Board17.2. Running the Demo on Two Boards2	7 8 1								
8.	Revision History	5								
Mic	rochip Information	6								
	The Microchip Website	5 5 6 6 7								
	Quality Management System	8 9								



1. Demo Requirements (Ask a Question)

The following table lists the hardware and software required for running the demo.

Requirement	Description						
Hardware and Accessories							
PolarFire evaluation kit	MPF300-EVAL-KIT						
	Two for two board demo and one for one board demo						
USB A to Micro-USB B cable	Required for:						
	FPGA programming						
	UART interface with the Wireless Demo GUI						
SMA cable	Female to Female						
	Required for providing the reference clock from evaluation kit to AD9528 on the AD9371 FMC card						
AD9371	Analog device's RF board for transceiver functionality and for digital signal processing function						
Linet DC							
HOST PC	A nost PC with USB port						
	I wo for two board demo and one for one board demo						
Power adapter	12V and 5A						
	Two for two board demo and one for one board demo						
Omnidirectional antenna	Required for transmitting or receiving the radio signal						
	Two (One for transmitting and other for receiving)						
Utility Software							
FlashPro Express v2023.1	To program the job file on PolarFire [®] SoC FPGA device						
Programming job file	PFEval_SDR						

Table 1-1. Demo Requirements



2. Demo Prerequisites (Ask a Question)

Before you start the demo, ensure that the following components are in place:

- 1. Download the design file from the following link: The programming job file is placed at <\$download_directory>\mpf_an5014_v2023p1_eval_df\Programming_File
- 2. For demo design files download link: www.microchip.com/en-us/application-notes/AN5014



3. Demo Design (Ask a Question)

The Libero design contains both the transmitter (Tx) path and receiver (Rx) path. The communication with the analog radio chip, AD9371, happens through JESD 204B. As the design has both transmitter and receiver paths, the demo is operated in the following two modes:

- 1. Two boards communication
- 2. Same board communication

3.1 Two Boards Communication Setup (Ask a Question)

This setup requires two PolarFire FPGA Evaluation kits, two AD9371 FMC cards, and two PCs to run the demo. Setting up the demo is described in 5. Setting Up the Demo section. The user data received from the GUI is transmitted over the air from the transmitter setup and is received at the receiver setup. The received radio data is demodulated and processed to extract the user data and is displayed on the GUI connected to the receiver setup.





3.2 Same Board Communication Setup (Ask a Question)

This setup requires one PolarFire FPGA Evaluation kit, one AD9371 FMC card and a PC to run the demo. The user data received from GUI is transmitted over the air and is received by the receiver on the same AD9371 FMC card. The received data is processed and displayed on the Receiver (Rx) tab of the same GUI that is used to send the user data.

Figure 3-2. Same Board Communication



3.3 Transmitter (Ask a Question)

The data to be transmitted is entered in the UART based Graphical User Interface (GUI) in the form of a text message or the text data is chosen from a text file. Each maximum SDR packet length is defined as 1024 Bytes. If the message is greater than 1024 Bytes, then the message is divided into chunks of 1024 Bytes data. The message is passed to FPGA through UART Interface and is stored in a FIFO. Once a complete packet is written into FIFO, the SDR packet is created by appending 64 Bytes access code and 2 Bytes of Packet length at the start of the packet. Final data transmitted from the packetization is 64 Bytes of access code + 2 Bytes of Packet Length + n Bytes of message (n is the size of the packet and is limited to 1024).



From Packetization, the message is further serialized from byte to bit in Parallel In Serial Out (PISO). Transformed bit data is further encoded using FEC Encoder with code rate of 1/2 to minimize the bit errors while transmitting in a noisy environment. The encoded data is modulated into Quadrature Phase Shift Keying (QPSK) constellation and then passed through the pulse shaping filter, which reduces the Inter Symbol Interference (ISI) and adjacent channel interference. Pulse shaped data is sent to AD9371 using JESD Interface. From AD9371, the data is transmitted through wireless medium to the receiver.





3.4 Receiver (Ask a Question)

The signal is received from the wireless medium and sent to the FPGA through AD9371 using the JESD interface at the receiver. The signal is further processed in the FPGA to recover the transmitted message or data and the incoming data from the JESD is stored in the FIFO. The DC removal block reads the data from the FIFO and removes the DC offset, which is then amplified in the AGC. The Costas loop (closed loop) is used to remove the phase offset. A Cascaded Integrator-Comb (CIC) filter decimated the phase and frequency corrected signal. Symbol Timing Synchronisation is used to find the optimal sampling instance of the filtered signal.

The MPSK demodulation block demodulates the data and is decoded in the Viterbi decoder. SIPO collects the bit data and converts it into byte data. The received data contains the access code and packet length, which need to be matched at depacketization and the data is separated from the packet structure and stored in a FIFO. The data is read from the FIFO through the UART interface and displayed in the GUI at the receiver end.

Figure 3-4. Process Flow in Receiver



3.5 Clocking Structure (Ask a Question)

The following figure shows the clocking structure of the design. PF_CCC_C0 generates the 50 MHz fabric clocks from the REF_CLK generated by PF_XCVR_REF_CLK. The on-board 156.25 MHz clock is the reference clock for the XCVR, which further provides the operating clock of 153.6 MHz for the TX_Path and RX_Path blocks.



Figure 3-5. Clocking Structure



3.6 Reset Structure (Ask a Question)

The following figure shows the reset structure of the demo design. The INIT_MONITOR IP asserts the following signals:

- FABRIC_POR_N: Asserted after the initialization of the fabric and this signal is used to reset the Mi-V and respective blocks.
- DEVICE_INIT_DONE: Asserted after the initialization of the PolarFire device.



Figure 3-6. Reset Structure





3.7 Resource Utilization and Performance (Ask a Question)

A summary of SDR resource utilization and performance data is shown in following figure.

Figure 3-7. SDR Device Resource Utilization and Performance

	Cable ALLT	C.L. DEF	1	La de Drr	C	D//	COMMENT	LICOMMANNY	11.11.110.10	Chine Chattale	D. CLAR	011	
odule Name	Fabric 4LUT	Fabric DFF	Interface 4LUT	Interface DFF	Single-Ended I/O	Differential I/O Pairs	USKAM 1K	LSRAM 18K	Math (18x18)	Chip Globals	Row Global	PLL	Iransceiver Lanes
Тор	21492	15284	26220	26220	26	3	46	669	44	14	9	3	5
Primitives	1	0	0	0	26	0	0	0	0	0	0	0	0
Proc_Sub_System_inst_0	8698	3452	19392	19392	0	0	8	536	0	5	0	1	0
SDR_inst_0	8479	7026	2292	2292	0	3	38	7	44	6	8	2	4
Primitives	2	0	0	0	0	1	0	0	0	0	0	0	0
E JESD_0	3236	2867	384	384	0	2	32	0	0	2	8	0	4
RX_Path_inst_0	4349	3237	600	600	0	0	2	6	10	3	0	1	0
Primitives	2	0	0	0	0	0	0	0	0	2	0	0	0
BYTE_ALLIGNMEN	77	36	0	0	0	0	0	0	0	0	0	0	0
CDC_video_fifo_0	69	88	72	72	0	0	0	2	0	0	0	0	0
E CORECIC CO I	313	765	0	0	0	0	0	0	0	0	0	0	0
E CORECIC CO Q	296	753	0	0	0	0	0	0	0	0	0	0	0
E COREFIFO C1 0	142	164	36	36	0	0	0	1	0	0	0	0	0
+ MPSK Demod C0 0	16	8	0	0	0	0	0	0	0	0	0	0	0
PE PE CCC C3.0	0	0	0	0	0	0	0	0	0	1	0	1	0
SIGNAL Condition	1351	620	144	144	0	0	0	0	4	0	0	0	0
E AGC inst 0	820	330	144	144	0	0	0	ů.	4	0	0	0	0
DC Removal I	93	73	0	0	0	0	0	0	0	0	0	0	0
DC_Removal_1	60	62	0	0	0	0	0	0	0	0	0	0	0
E IO MAG AVG O	370	145	0	0	0	0	0	0	0	0	0	0	0
SIDO O	370	142	0	0	0	0	0	0	0	0	0	0	0
SIPO_0	24	34	0	0	0	0	0	0	0	0	0	0	0
+ Viterbi_Decoder_C	298	225	108	108	0	0	0	3	0	0	0	0	0
t costas_top_C1_0	1269	217	216	216	0	0	0	0	6	0	0	0	0
depacketization_0	120	56	0	0	0	0	0	0	0	0	0	0	0
read_fifo_logic_0	8	16	0	0	0	0	0	0	0	0	0	0	0
timing_sync_0	357	255	24	24	0	0	2	0	0	0	0	0	0
- xor20bit_0	7	0	0	0	0	0	0	0	0	0	0	0	0
STATUS_LED_0	6	8	0	0	0	0	0	0	0	0	0	0	0
TX_Path_inst_0	751	578	1308	1308	0	0	4	1	34	1	0	1	0
Primitives	1	0	0	0	0	0	0	0	0	0	0	0	0
COREFIFO_C0_0	144	156	36	36	0	0	0	1	0	0	0	0	0
DATA RATE GENER	46	35	0	0	0	0	0	0	0	0	0	0	0
FEC Encoder C0 0	3	9	0	0	0	0	0	0	0	0	0	0	0
GUARD Band SIG	98	85	0	0	0	0	0	0	0	0	0	0	0
MUX IO VLD 0	44	47	0	0	0	0	0	0	0	0	0	0	0
PISO 1	54	38	0	0	0	0	0	0	0	0	0	0	0
- Interpolator Block 0	97	125	1272	1272	0	0	4	0	34	0	0	0	0
+ CORFEIR PE C	31	34	636	636	0	0	2	0	17	0	0	0	0
E CORFEIR PE C	32	41	636	636	0	0	2	0	17	0	0	0	0
LIPSampling	34	50	0	0	0	0	0	0	0	0	0	0	0
E MPSK Mod C0.0	47	32	0	0	0	0	0	0	0	0	0	0	0
MCC : 0	47	32	0	0	0	0	0	0	0	0	0	ő	0
MISC_[9	0	0	0	0	0	0	0	0	0	1	0	1	0
DICO int O	61	45	0	0	0	0	0	0	0		0		0
PISU_INST_0	01	43	0	0	0	0	0	0	0	0	0	0	0
packetization_inst_0	135	226	0	0	0	0	0	0	0	0	0	0	0
UARI_interface_0	135	330	0	0	0	0	0	0	0	0	0	0	0
COREUART_CO_0	88	79	0	0	0	0	0	0	0	0	0	0	0
addr_decoder_V2_0	20	181	0	0	0	0	0	0	0	0	0	0	0
receive_data_v2_0	27	76	0	0	0	0	0	0	0	0	0	0	0
UART_TX_MUX_0	2	10	0	0	0	0	0	0	0	0	0	0	0
ident_coreinst	4312	4796	4536	4536	0	0	0	126	0	3	0	0	0
+ refclock 0	0	0	0	0	0	0	0	0	0	0	1	0	1

3.8 Ports (Ask a Question)

The following table lists the ports of the demo design.

Direction	Description							
Input	XCVR Reference clock 156.25 MHz							
Output	XCVR serial data							
neral Ports								
Input	XCVR Reference clock input							
Input	Sync signal from AD9371							
Input	SYSREF signal from AD9371 FMC card							
	Direction Input Output Input Input Input Input Input							

Table 3-1. Input and Output Ports



continued		
Port Name	Direction	Description
LANE3_RXD_N LANE3_RXD_P LANE2_RXD_N LANE2_RXD_P LANE1_RXD_N LANE1_RXD_P LANE0_RXD_N LANE0_RXD_P	Input	Transceiver lanes connected to AD9371
ADC_SYNC_P ADC_SYNC_N	Output	Sync signal to AD9371
LED_OUT	Output	Connected to LEDs on EVAL kit
LANE3_TXD_N LANE3_TXD_P LANE2_TXD_N LANE2_TXD_P LANE1_TXD_N LANE1_TXD_P LANE0_TXD_N LANE0_TXD_P	Output	Transceiver lanes connected to AD9371
MSS Peripheral Ports		
REF_CLK_0	Input	On Board 50 MHZ reference clock
TRSTB	Input	CoreJTAG pin
ТСК	Input	CoreJTAG pin
TDI	Input	CoreJTAG pin
TMS	Input	CoreJTAG pin
SPI_SDI	Input	SPI Data input
TDO	Output	CoreJTAG pin
SPI_SCLK	Output	SPI Clock
SPI_SDO	Output	SPI Data out
SPI_SS0	Output	SPI chip select
SPI_SS1	Output	SPI chip select
GPIO_OUT	Output	GPIO[3] → reset JESD sub system GPIO[2] → UART MUX GPIO[4-9] → Connected to AD9371
UART Ports		
RX	Input	UART receiver for both UARTapb and CoreUART
TX	Output	UART transmitter for both UARTapb and CoreUART



4. Installing the Software Defined Radio Demo GUI (Ask a Question)

To install the Software Defined Radio demo GUI, perform the following steps:

- Extract the contents of the mpf_an5014_v2023p1_eval_df.zip file and run the setup.exe file from mpf_an5014_v2023p1_eval_df/GUI/ Software_Defined_Radio_Demo_GUI_Installer/.
- 2. Click **Yes** for any message from User Account Control. The Software Defined Radio demo GUI installation wizard is displayed.
- 3. Confirm the installation directory locations for the GUI and the National Instruments products and click **Next**.
- 4. Accept the license agreement and click **Next**.
- 5. Review the summary and click **Next**, then the installation proceeds with a progress bar. After the installation, a confirmation message is displayed.
- 6. Click **Next** to exit the installation wizard.
- 7. Restart the host PC when prompted. The Software Defined Radio demo GUI is installed.



5. Setting Up the Demo (Ask a Question)

The demonstration involves the following steps:

- 1. Setting up the hardware
 - For same board communication
 - For two boards communication
- 2. Programming the device

5.1 Setting Up the Hardware (Ask a Question)

After generating the bitstream, the PolarFire device is programmed on Evaluation kit by performing the following steps:

1. Ensure that the jumper settings on the board are same as listed in the following table.

5							
Description							
Close pin 2 and 3 for programming the PolarFire FPGA through FTDI							
Close pin 1 and 2 for programming through the on-board FlashPro5							
Close pin 1 and 2 for programming through the FTDI SPI							
Close pin 1 and 2 for programming through the FTDI SPI							
Close pin 1 and 2 for manual power switching using SW3							
Close pin 3 and 4 for 2.5 V							
Remain open							
Switch 1 and 2. Selects Tx and Rx LO (Local Oscillator) frequency in AD9371. For more information, see 7. Changing the Tx and Rx frequency section.							
Reset switch							

Table 5-1. Jumper Settings

2. Connect the power supply cable to the J9 connector on the board.

3. Connect the USB cable from the host PC to the J5 (FTDI port) on the board.

- 4. Power on the board using the SW3 slide switch.
- 5. For external loop back demo, connect TX1 to RX1 using the 1 SMA to SMA cables.



The following figure shows the board setup for the mentioned jumper settings.



Figure 5-1. PolarFire FPGA Evaluation Kit Jumper Settings for SDR

When the board is powered up, power supply LEDs DS3 to DS14 is switched on. For more information about LEDs on the PolarFire FPGA Evaluation Kit, see UG0747: PolarFire FPGA Evaluation Kit User Guide.

5.1.1 Same Board Communication (Ask a Question)

To setup same board communication, perform the following steps:

- 1. Connect the AD9371 with the FMC Connector of the PolarFire FPGA Evaluation kit.
- 2. Connect the SMA antenna at the transmitter and other SMA antenna at the receiver part as shown in the Figure 7-2.
- 3. Ensure that the jumper setting are as per the Table 5-1 and power up the board.

5.1.2 Two Boards Communication (Ask a Question)

To setup two boards communication, perform the following steps:

- 1. Connect the AD9371 with the FMC Connector of the PolarFire FPGA Evaluation kit and follow the same for the other board.
- 2. Connect the SMA antenna at the Transmitter of board 1 and connect the other antenna at the receiver of the board 2 as shown in Figure 7-1.
- 3. Ensure that the jumper settings are as per the Table 5-1, and the board is powered up and the same must be done with the second board.

5.2 Programming the Device (Ask a Question)

This section describes how to program the PolarFire FPGA Evaluation kit with the job file using FlashPro Express. To program the device, perform the following steps:

The PFEval SDR.job file is available at mpf an5014 v2023p1 eval df\Programming File.



- 1. Connect a micro USB to **J5** from the host PC and start the FlashPro Express software from its installation.
- 2. Select **New** or **New Job Project** from the Project menu to create a new job project, as shown in the following figure.

Figure 5-2. FlashPro Express Job Project



- 3. In the **FlashPro Express Job** dialog box, enter the following values in the New Job Project:
 - Programming job file: Click Browse, and navigate to the location where the .job file is located and select the file. The default location is:
 <\$download directory>\mpf an5014 v2023p1 eval df\Programming File.
 - **FlashPro Express job project location**: Click **Browse**, and navigate to the location where you want to save the project.
- 4. Click **OK**. The required programming file is selected and ready to be programmed in the device.
- 5. The FlashPro Express window appears as shown in the following figure. Confirm that a programmer number (for example, 79DE6C53) appears in the Programmer field. If it does not, then confirm the board connections and click **Refresh/Rescan Programmers**.

Figure 5-3. Programming the Device



6. Click **RUN**. When the device is programmed successfully, a **RUN PASSED** status is displayed as shown in the following figure.



Figure 5-4. FlashPro Express—RUN PASSED

miert View Tools Help										
Refresh Rescan Programmers	· · · · · · · · · · · · · · · · · · ·									
Programmer	0 NF730075									
	AVERATE AVERATION AVERATE AVE									
RUN	1 PROGRAMMER(S) PASSED									

- 7. Close FlashPro Express or in the Project tab, click Exit.
- 8. Power cycle the board using **SW5**.



6. SoftConsole (Ask a Question)

The softconsole project included with the Libero design, uses the APIs for AD9371 and AD9528 from analog devices which are used to initialize and configure the clock generator AD9528. The RF transceiver AD9371 which has a built in ARM processor that runs calibration and other power up sequences required to initialize AD9371. The ARM binary byte file required for the built in ARM processor is loaded by the soft Mi-V processor in the FPGA power up sequence, which indeed communicates with AD9371 and AD9528 by Serial Peripheral Interface (SPI). The Mi-V processor reads the status of AD9528 and AD9371 through SPI during initialization and displays the status on UART terminal.

The following listed messages are displayed on the **Receive Data** window:

- **SPI AD9371**: Before the SPI communication in the Mi-V processor with AD9371 (and AD9528) is initiated, it is displayed on the screen only after the appropriate UART initialization. If this message is not displayed or some random data is displayed on the GUI, then check the UART baudrate value in the GUI.
- **PLL Locked**: The Mi-V processor checks the status of the CLKPLLL bit and when CLKPLL is locked, this message is displayed. If not locked, then **PLL not locked** is displayed.
- **Multi Chip Sync Successful**: After performing Multi Chip Sync, the Mi-V processor verifies if the Multi Chip Sync is successful or not. This message is displayed if it is successful. If not, then **Multi Chip Sync Failed** is displayed.
- **AD9371 ARM Version 4.0.6**: After loading an ARM binary byte file, the Mi-V processor reads back the version of the binary just loaded by it. This message is displayed if binary byte array is properly loaded and the version is read back. If not loaded properly, then an arbitrary number is displayed.
- (CLK, RX, TX, SNIFFER) PLLs Locked: This message is displayed when the Mi-V processor checks for the PLL locks for CLK, RX, TX, and sniffer. If not locked, it displays the message (CLK, RX, TX, SNIFFER) PLLs not locked along with PLL lock status. For more information about PLL status bits, see the UG992 AD9371 user guide for analog devices.
- **Calibrations Completed Successfully**: The Mi-V processor queries the calibration status of AD9371. This message is displayed if the ARM processor (in the AD9371) successfully completes calibrations. Otherwise, this message is not displayed.
- **Successfully Initialised AD9371**: This is the final message. It is displayed when AD9371 is initialized and configured correctly. If AD9371 is not configured correctly or it fails to initialize, then the message **Initialization Failed**, **Status =XXXX**, is displayed along with the status bits (indicated as XXXX). The status bits are used to debug failures during initialization.



7. Running the Demo (Ask a Question)

To execute the demo, perform the following steps:

- 1. After programming the PolarFire FPGA Evaluation kit, connect AD9371 to the FMC connector.
- 2. Connect the SMA cable to the J41 pin on the PolarFire FPGA Evaluation kit and J401 on the AD9371. This acts as the reference clock to the FMC card.
- 3. Depending on the type of the demo being used, connect the antennas to the respective transmitter and receiver of the FMC card. if demo is running on two boards, connect one antenna to J305 (Tx1) of the first demo kit and connect second antenna to J200 (Rx1) of the second demo kit.



Figure 7-1. Setting Up of Two PolarFire Evaluation Kit with AD9371

4. For running the demo on the same board, connect one antenna to J305 (Tx1) and second antenna to the J200 (Rx1) of the same board.



Figure 7-2. Setting Up of PolarFire Evaluation Kit with AD9371

This SDR demo features the transmit and receive the data or image in the wireless medium. The data is transmitted through UART from GUI to the transmitter, then the data sent is packed, encoded, and modulated. The final modulated data is transmitted over the air and received at the receiver end.

Changing the Tx and Rx frequency

SDR demo runs in four different LO frequencies. Use the DIP switch SW11 to modify the LO frequency – ensure to configure the same frequency on the transmit and receive sides. In the two-board demonstration, the distance between the antennas is determined by the configured frequency. The following table lists the available LO frequencies.

Switch [2:1]	LO Frequency							
ON : ON	700 MHz							
ON : OFF	1200 MHz							
OFF : ON	2400 MHz							
OFF : OFF	5800 MHz							

Table 7-1. Frequency Settings



Important: Make sure to toggle reset (SW5) after changing the LO Frequency.

7.1 Running the Demo on Same Board (Ask a Question)

To run demo on same board, perform the following steps:



1. After programming the bit files, launch the GUI, see the following figure.

Figure 7-3. Displayed GUI

File Connection View														
	⊳	₽'n	៨	C		r ₁₀	6	៨			Soft	ware Defined	Radio Demo	
Tx & Rx	Tx Da	ata							0 bytes	Rx Data			0	bytes
ii Tx									^					^
i ≥×														
View Image														
									~					~
~ ``` `											Tx & Rx Mode	ASCII	\Lambda Discon	nected

2. On the **Connection** tab, point to COM Port, click **Refresh Ports** and then click the appropriate (3rd port corresponding to Flashpro - COM9) **COM Port** connected to the PC.

Figure 7-4. Com Port Connection

File Cor	nnection View	v								
	COM Port >	COM10 COM7 COM8	F	6	៨			Softwar	e Defined Rad	lio Demo
Tx & R	x Tx D	COM9 Refresh Ports				0 bytes	Rx Data			0 bytes
ii ™										
Rx Rx										
View Ima	age									
						~				~
N								Tx & Rx Mode	ASCII	A Disconnected

3. On the **Connection** tab, click **Connect**.



Figure 7-5. Connection Establishment

File Connecti	ion View						
COM F Conne	Port 🕨 🕞	៨	F=	F 2 (3	៨	So	ftware Defined Radio Demo
Tx & Rx	Tx Data				0 bytes	Rx Data	0 bytes
∰ Tx							
₿ Rx							
View Image							
					~		v
						Tx & Rx Mod	le 🕴 ASCII 🕴 COM9 🛕 Disconnected

4. Check for the connection status at right bottom corner of the GUI.

Figure 7-6. Connection Status

сомя 📀	Connected
--------	-----------

After successful connection, setup is ready for the wireless transfer of data. In the **Tx Data** box, type text data and click

Figure 7-7. Data Sent from Transmitter Side

The connect									
	₽₽	៨			ഫ് 1		Software Defined	l Radio Demo	
Tx & Rx Tx & Rx Tx Rx View Image	Tx Data Hello Microchi	p from Softw	vare Defined R	adio Demo	0 bytes	Rx Data		0 bytes	
					~		14 1 1 1000 1		
						IX & RO	ASCII	COIVIS Connected	



6. After successful transfer, the received data must appear in the **Rx Data** box.

Figure 7-8. Data Received at Receiver Side

File Connecti	ion Viev	N								
	₽	₽₀	៨	Ē	ß	6	៨		Software Defined Radi	io Demo
E Tx & Rx	Tx Da Hello	ata Microchi	ip from So	oftware Defi	ned Radio) Demo		48 bytes	Rx Data Hello Microchip from Software Defined Radio Demo	48 bytes
tx ™										
₽ ×										
View Image										
								~		>
<i>.</i>									Tx & Rx Mode ASCII COM9	✓ Connected

7.2 Running the Demo on Two Boards (Ask a Question)

To run demo on two boards, perform the following steps:

- 1. Place the Transmitter (Tx) and Receiver (Rx) antennas with in 1 meter range. The range limitation is due to the limited RF gain of AD9371. The range is extended by using a RF amplifier at transmitter output.
- 2. After programming the bit files, launch the GUI in the PC where Transmitter antenna is connected.
- 3. Select the appropriate port for the communication in **Connection** tab and click **Connect**.
- 4. Check for the connection status at right bottom corner of the GUI.

Figure 7-9. Connection Status



- 5. By this, point connection is established and GUI is ready to send or receive the data.
- 6. Repeat the same steps for the PC connected to the Receiver antenna.
- 7. You can send data in the following two ways:
 - a. Enter data and click **Send**
 - b. Click Send from File

The following figure is an example where data is sent by clicking Send.



Figure 7-10. Data Sent from Transmitter Side

₽	b d 🛛 🛱	E 10 á	Software Defined Radio Demo
Tx & Rx Tx & Rx	I	and Padia Dama using two boards	0 bytes
	icrochip from Software Den	ied kadio Demo using two boards	
iii ≈			
View Image			
<u></u>			·
			Tx & Rx Mode ASCII COM9 🥑 Connected

- 8. After data is entered, click **Send**
- 9. After a successful transfer, the message is displayed on the receive data window on the GUI connected to the RX antenna.

Figure 7-11. Data Received at Receiver Side

The connect	on new							
	⊳	Þa	ធ	Ē		6	ର୍ଗ	Software Defined Radio Demo
1x & Rx	Rx Dat	a						66 bytes
tx	Hello N	licrochip	from Soft	tware Defi	ned Radi	o Demo	using tw	vo boards
Rx								
View Image								
								•
								Tx & Rx Mode 🔋 ASCII 🔋 COM9 🕑 Connected

SDR demo also supports sending .jpg image. To transfer image, perform the following steps:

1. Click on **Send file**, select the .jpg file through the popup browser window and click **Send**



Figure 7-12. File Selection

File Connect	lion	View											← → × ∧ 🚺		✓ → Ø Search Temp
		> 🗞	៨	F	R	6	á			Software De	fined Radio Demo		Organize 🔻 New folde		
Tx & Rx Tx & Rx Tx Rx		Tx Data						0 bytes	Rx Data		0 byt	es ^	A Quick access Desktop ≠ Downloads ≠ Documents ≠ Pictures ≠ QPSk ≠ 30th May	Microchip Ø Microchip Log ojipg	
Niew Image													T 700M-E GUI (mage: GUI (mage: Guil) mage: Chelbine - Microl This PC B Documents Downloads Micro: Pictures Micros Windows (C) ↓		
₫	_							*	Tx & F	Rx Mode ASCII	COM9 Oconnecte	¥ d	File na	ime:	v text files or image files (".txt*jg v OK Cancel .i

2. After successful transfer of the image, to see the received image, click **View image**

Figure 7-13. After Successful Transfer

File Connect	ion vie	WV.							
	⊳	₽'n	៨	Ē	E2	6	ක්	Software Defined Radio	Demo
Tx & Rx	Rx	lmage							186 x 800 pixels
ti Tx									
Rx Rx									
View Image				8					
		X	X	Λ.	Λ	Λ	1		
	<								>
~ ``` `								Tx & Rx Mode ASCII COM9 🤆	Connected

3. After successful image reception at Rx, on the **View** tab, click **Clear all** before sending the next data/image.



Figure 7-14. Clear Data for Sending Next Data/Image





8. Revision History (Ask a Question)

The revision history describes the changes that were implemented in the document. The changes are listed by revision, starting with the most current publication.

Table 8-1. Revision History

Revision	Date	Description
1	06/2023	Initial release



Microchip Information (Ask a Question)

The Microchip Website (Ask a Question)

Microchip provides online support via our website at www.microchip.com/. This website is used to make files and information easily available to customers. Some of the content available includes:

- Product Support Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip design partner program member listing
- Business of Microchip Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

Product Change Notification Service (Ask a Question)

Microchip's product change notification service helps keep customers current on Microchip products. Subscribers will receive email notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, go to www.microchip.com/pcn and follow the registration instructions.

Customer Support (Ask a Question)

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Embedded Solutions Engineer (ESE)
- Technical Support

Customers should contact their distributor, representative or ESE for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in this document.

Technical support is available through the website at: www.microchip.com/support

Microchip Devices Code Protection Feature (Ask a Question)

Note the following details of the code protection feature on Microchip products:

- Microchip products meet the specifications contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is secure when used in the intended manner, within operating specifications, and under normal conditions.
- Microchip values and aggressively protects its intellectual property rights. Attempts to breach the code protection features of Microchip product is strictly prohibited and may violate the Digital Millennium Copyright Act.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of its code. Code protection does not mean that we are guaranteeing the product is "unbreakable". Code protection is constantly evolving. Microchip is committed to continuously improving the code protection features of our products.

Legal Notice (Ask a Question)

This publication and the information herein may be used only with Microchip products, including to design, test, and integrate Microchip products with your application. Use of this information in any other manner violates these terms. Information regarding device applications is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure



that your application meets with your specifications. Contact your local Microchip sales office for additional support or, obtain additional support at www.microchip.com/en-us/support/design-help/ client-support-services.

THIS INFORMATION IS PROVIDED BY MICROCHIP "AS IS". MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE, OR WARRANTIES RELATED TO ITS CONDITION, QUALITY, OR PERFORMANCE.

IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL LOSS, DAMAGE, COST, OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE INFORMATION OR ITS USE, HOWEVER CAUSED, EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP'S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THE INFORMATION OR ITS USE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THE INFORMATION.

Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks (Ask a Question)

The Microchip name and logo, the Microchip logo, Adaptec, AVR, AVR logo, AVR Freaks, BesTime, BitCloud, CryptoMemory, CryptoRF, dsPIC, flexPWR, HELDO, IGLOO, JukeBlox, KeeLoq, Kleer, LANCheck, LinkMD, maXStylus, maXTouch, MediaLB, megaAVR, Microsemi, Microsemi logo, MOST, MOST logo, MPLAB, OptoLyzer, PIC, picoPower, PICSTART, PIC32 logo, PolarFire, Prochip Designer, QTouch, SAM-BA, SenGenuity, SpyNIC, SST, SST Logo, SuperFlash, Symmetricom, SyncServer, Tachyon, TimeSource, tinyAVR, UNI/O, Vectron, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

AgileSwitch, APT, ClockWorks, The Embedded Control Solutions Company, EtherSynch, Flashtec, Hyper Speed Control, HyperLight Load, Libero, motorBench, mTouch, Powermite 3, Precision Edge, ProASIC, ProASIC Plus, ProASIC Plus logo, Quiet- Wire, SmartFusion, SyncWorld, Temux, TimeCesium, TimeHub, TimePictra, TimeProvider, TrueTime, and ZL are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, Augmented Switching, BlueSky, BodyCom, Clockstudio, CodeGuard, CryptoAuthentication, CryptoAutomotive, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, Espresso T1S, EtherGREEN, GridTime, IdealBridge, In-Circuit Serial Programming, ICSP, INICnet, Intelligent Paralleling, IntelliMOS, Inter-Chip Connectivity, JitterBlocker, Knob-on-Display, KoD, maxCrypto, maxView, memBrain, Mindi, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, PowerSmart, PureSilicon, QMatrix, REAL ICE, Ripple Blocker, RTAX, RTG4, SAM-ICE, Serial Quad I/O, simpleMAP, SimpliPHY, SmartBuffer, SmartHLS, SMART-I.S., storClad, SQI, SuperSwitcher, SuperSwitcher II, Switchtec, SynchroPHY, Total Endurance, Trusted Time, TSHARC, USBCheck, VariSense, VectorBlox, VeriPHY, ViewSpan, WiperLock, XpressConnect, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

The Adaptec logo, Frequency on Demand, Silicon Storage Technology, and Symmcom are registered trademarks of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.



© 2023, Microchip Technology Incorporated and its subsidiaries. All Rights Reserved.

ISBN: 978-1-6683-2659-6

Quality Management System (Ask a Question)

For information regarding Microchip's Quality Management Systems, please visit www.microchip.com/quality.



Worldwide Sales and Service

AMERICAS	ASIA/PACIFIC	ASIA/PACIFIC	EUROPE
Corporate Office	Australia - Sydney	India - Bangalore	Austria - Wels
2355 West Chandler Blvd.	Tel: 61-2-9868-6733	Tel: 91-80-3090-4444	Tel: 43-7242-2244-39
Chandler, AZ 85224-6199	China - Beijing	India - New Delhi	Fax: 43-7242-2244-393
Tel: 480-792-7200	Tel: 86-10-8569-7000	Tel: 91-11-4160-8631	Denmark - Copenhagen
Fax: 480-792-7277	China - Chengdu	India - Pune	Tel: 45-4485-5910
Technical Support:	Tel: 86-28-8665-5511	Tel: 91-20-4121-0141	Fax: 45-4485-2829
www.microchip.com/support	China - Chongqing	Japan - Osaka	Finland - Espoo
Web Address:	Tel: 86-23-8980-9588	Tel: 81-6-6152-7160	Tel: 358-9-4520-820
www.microchip.com	China - Dongguan	Japan - Tokyo	France - Paris
Atlanta	Tel: 86-769-8702-9880	Tel: 81-3-6880- 3770	Tel: 33-1-69-53-63-20
Duluth, GA	China - Guangzhou	Korea - Daegu	Fax: 33-1-69-30-90-79
Tel: 678-957-9614	Tel: 86-20-8755-8029	Tel: 82-53-744-4301	Germany - Garching
Fax: 678-957-1455	China - Hangzhou	Korea - Seoul	Tel: 49-8931-9700
Austin, TX	Tel: 86-571-8792-8115	Tel: 82-2-554-7200	Germany - Haan
Tel: 512-257-3370	China - Hong Kong SAR	Malaysia - Kuala Lumpur	Tel: 49-2129-3766400
Boston	Tel: 852-2943-5100	Tel: 60-3-7651-7906	Germany - Heilbronn
Westborough, MA	China - Nanjing	Malaysia - Penang	Tel: 49-7131-72400
Tel: 774-760-0087	Tel: 86-25-8473-2460	Tel: 60-4-227-8870	Germany - Karlsruhe
Fax: 774-760-0088	China - Qingdao	Philippines - Manila	Tel: 49-721-625370
Chicago	Tel: 86-532-8502-7355	Tel: 63-2-634-9065	Germany - Munich
ltasca, IL	China - Shanghai	Singapore	Tel: 49-89-627-144-0
Tel: 630-285-0071	Tel: 86-21-3326-8000	Tel: 65-6334-8870	Fax: 49-89-627-144-44
Fax: 630-285-0075	China - Shenyang	Taiwan - Hsin Chu	Germany - Rosenheim
Dallas	Tel: 86-24-2334-2829	Tel: 886-3-577-8366	Tel: 49-8031-354-560
Addison, TX	China - Shenzhen	Taiwan - Kaohsiung	Israel - Ra'anana
Tel: 972-818-7423	Tel: 86-755-8864-2200	Tel: 886-7-213-7830	Tel: 972-9-744-7705
Fax: 972-818-2924	China - Suzhou	Taiwan - Taipei	Italy - Milan
Detroit	Tel: 86-186-6233-1526	Tel: 886-2-2508-8600	Tel: 39-0331-742611
Novi, MI	China - Wuhan	Thailand - Bangkok	Fax: 39-0331-466781
Tel: 248-848-4000	Tel: 86-27-5980-5300	Tel: 66-2-694-1351	Italy - Padova
Houston, TX	China - Xian	Vietnam - Ho Chi Minh	Tel: 39-049-7625286
Tel: 281-894-5983	Tel: 86-29-8833-7252	Tel: 84-28-5448-2100	Netherlands - Drunen
Indianapolis	China - Xiamen		Tel: 31-416-690399
Noblesville, IN	Tel: 86-592-2388138		Fax: 31-416-690340
Tel: 317-773-8323	China - Zhuhai		Norway - Trondheim
Fax: 317-773-5453	Tel: 86-756-3210040		Tel: 47-72884388
Tel: 317-536-2380			Poland - Warsaw
Los Angeles			Tel: 48-22-3325737
Mission Viejo, CA			Romania - Bucharest
Tel: 949-462-9523			Tel: 40-21-407-87-50
Fax: 949-462-9608			Spain - Madrid
Tel: 951-273-7800			Tel: 34-91-708-08-90
Raleigh, NC			Fax: 34-91-708-08-91
Tel: 919-844-7510			Sweden - Gothenberg
New York, NY			Tel: 46-31-704-60-40
Tel: 631-435-6000			Sweden - Stockholm
San Jose, CA			Tel: 46-8-5090-4654
Tel: 408-735-9110			UK - Wokingham
Tel: 408-436-4270			Tel: 44-118-921-5800
Canada - Toronto			Fax: 44-118-921-5820
Tel: 905-695-1980			
Fax: 905-695-2078			